


Aluminium frame - Steel cable + suspended ceiling attachment

1



Feed the cable through the top edge of the frame locating end stop ferrule in centre groove of the frame, slide sign(s) in place through the side entrance aperture.

2



Simply position the ceiling grid clip in the desired location, twist and lock in place onto the ceiling grid.

3



Locate disc cover over the ceiling grid clip, securing in position by threading the cable clamp onto the ceiling grid clip. Feed cable into clamp through the entrance boss, cable adjustment can be made by pressing the entrance boss.



Frame option code: SS2-2-

Aluminium 7010 Sign System - Cable/suspended ceiling attachment

